



# AX1702

## Hard skid plate

### KTM 790/890 Adventure R/L

#### What's in the box ?

- 2 NE09-01-001 - Silent blocks
- 1 PM03-04-103 - Alloy part
- 1 PM03-04-104 - Alloy part
- 2 NE03-01-019 - Alloy spacers
- 1 NE04-01-262 - Sticker kit
- 1 PM03-04-126 - Left alloy part
- 1 PM03-04-127 - Right alloy part
- 1 PM01-10-023 - 30mm HDPE block
- 1 PM01-06-080 - 8mm mud guard
- 14 NE01-02-002 - TFHC 6x20mm screws
- 16 NE01-04-003 - EM6F bolts
- 16 NE01-03-001 - M6 washers
- 2 NE01-02-003 - TFHC 6x25mm screws
- 4 NE01-11-001 - Special screws
- 2 NE13-01-001 - 8mm foam sticker



# Assembling instructions

Approximate time of assembly: 30 minutes.


A skid plate is made to protect the vital components of your bike and does not have a « life warranty ». However, production default may happen and we cover it during the first year of use.

In case of premature breakage, please write to [contact@axpracing.com](mailto:contact@axpracing.com)


#### Follow the steps



1  
Stick the foam in the middle of the skid plate.



2  
Cut the foam and stick both parts on each side of the skid plate.




3  
Place the HDPE block using 2 TFHC 6x25mm screws + M6 washers and EM6F bolts.



4  
Fix the alloy parts on each side of the skid plate using 3 TFHC 6x20mm screws + M6 washers and EM6F bolts.



5  
Fix the alloy parts on each side of the skid plate using 3 TFHC 6x20mm screws + M6 washers and EM6F bolts.



6  
Fix the alloy parts on each side of the skid plate using 4 TFHC 6x20mm screws + M6 washers and EM6F bolts.

The paper instructions may be limitless, scan the QR code to watch the tutorial video online.







7  
Screw the two silent blocks in the engine.




8  
Remove the OEM spacer under the footpeg.




9  
Untighten the OEM screw, without removing it completely.




10  
Place the skid plate and put 2 special screws, without tightening them.



11  
Lift the skid plate up to align the holes.



12  
Put the spacer in place.



13  
Use the OEM screw to keep the spacer in place without tightening. Repeat the operation on the other side.



14  
Tighten the front screws and then tighten the screws on each side.



15  
Place the mudguard in front of the skid plate and tighten the 2 special screws.

**You're  
all ready  
to ride !**