



LAH.04.11300
KTM 890 Adventure R
Upper Light Mounting Bracket


Thank you for choosing DENALI
We know you would rather be riding your bike than wrenching on it, so we go the extra mile to make sure our instructions are clear and as easy to understand as possible. If you have any questions, comments, or suggestions don't hesitate to give our gear experts a call at 401.360.2550 or visit WWW.DENALIELECTRONICS.COM

Please Read Before Installing
DENALI products should always be installed by a qualified motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. DENALI takes no responsibility for damages caused by improper installation. **Caution:** When installing electronics it is extremely important to pay close attention to how wires are routed, especially when mounting products to the front fender, front forks, or fairing of your motorcycle. Always be sure to turn the handlebars fully left, fully right, and fully compress the suspension to ensure the wires will not bind and have enough slack for your motorcycle to operate properly.


Installation Tips
We strongly recommend using medium strength liquid thread locker on all screws, nuts, and bolts. It is also important to ensure that all hardware is tightened to the proper torque specifications as listed in your owner's manual. For included accessory hardware please refer to the default torque specifications provided below. Inspect all hardware after the first 30 miles to ensure proper torque specifications are maintained.

Bolt Size	in-lbs	ft-lbs	Nm
M3	10.0 in-lbs	-	1.0 Nm
M4	23.0 in-lbs	-	2.5 Nm
M5	44.5 in-lbs	3.5 ft-lbs	5.0 Nm
M6	78.0 in-lbs	6.5 ft-lbs	9.0 Nm
M8	-	13.5 ft-lbs	18.0 Nm
M10	-	30.0 ft-lbs	41.0 Nm
M12	-	52.0 ft-lbs	71.0 Nm

Hardware Sizing Guide
Not sure what size bolt you have? Use this ruler to measure screws, bolts, spacers, etc. Remember, the length of a screw or bolt is measured from the start of the "mounting surface" to the end of the screw, so only include the screw head when measuring countersunk screws.



What's In The Box?



Kit Contents

- (a) Right Hand Side Mounting Bracket...LAH.04.11300-02.....Qty 1

(b) Left Hand Side Mounting Bracket...LAH.04.11300-01.....Qty 1

(c) M5 x 20mm Button Head Screw DIN 7380.....Qty 4


(d) Upper Spacer...LAH.04.11300-03.....Qty 4
- (e) Lower Spacer...LAH.04.11300-04.....Qty 2

(f) M5 Washer DIN 125.....Qty 6

(g) M5 x 25mm button Head Screw DIN 7380.....Qty 2

Tools Required: 3mm Hex Bit

1. Installing The Light Mount



1.1 - Location Prep & Installation

Step One: Starting on either side, locate the three mounting points for each bracket and remove the factory screws. Two are located close to the top of the inner fairing near the triple tree. The third one is on the lower left and right corner of the inner fairing near the radiator.

Step Two: Mount the Left hand bracket (b) with the hardware shown in the above exploded view.

Step Three: Repeat step Two with the Right Hand bracket (a).

Step Four: Once both brackets (a,b) are installed make sure the mounting shelves are level with each other and the ground. Next install your lights above or below the mounting shelf and check that they clear the path of the motorcycles forks.